



Increased power transfer and longer belt and one way bearing life.

1. Motor Pulley.



2. Belt Tensioner.




NOTE:


- For proper belt tension alignment:
- Assemble the tensioner arm as shown
 - Cut the main frame where highlighted




3. One Way Pulley.



4. Tail Servo.



5. Motor Belt Assembly.



Sequence:

- Install the motor and motor pulley to its mounting plate.
- Fit the motor assembly into position.
- Compress the springs by pushing the motor toward the main shaft.
- At maximum compression, temporarily tighten one of the slide nuts.
- Engage the belt around the motor pulley.
- Engage the belt around the main pulley.
- Rotate the motor several times by hand.
- Loosen up the slide nut to allow the springs to tension the belt.
- Help the springs by pulling on the motor slightly.
- Lock both slide nuts and front screws.
- **The belt must be very tight.**

6. Spare Parts.

H0171-S	One Way Double Bearing.
H0172-S	Font Tail Pulley Low.
H0173-S	Tail Servo Spacer
H0175-18-S	Motor Pulley 18T 20mm.
H0175-19-S	Motor Pulley 19T 20mm.
H0175-20-S	Motor Pulley 20T 20mm.
H0175-21-S	Motor Pulley 21T 20mm.
H0175-22-S	Motor Pulley 22T 20mm.
H0175-23-S	Motor Pulley 23T 20mm.
HC309-S	Big Motor Belt 770