

STRATOS 200



Green screw means
you need to use :
**Thread Locker High
Strength**




Blue screw means you
need to use :
**Thread Locker Medium
Strength**




Black screw / nuts-
means you don't need
to use Thread Locker


Main Rotor Head Assembly Part 1




Swashplate Assembly




Main Rotor Head Assembly Part 2




Main Shaft Installation



Swashplate & Radius Arm Installation



Linkages Installation



Main Hub SET

XL20H140



- 1 x Center Hub 3-blade.
- 3 x POM Damper.
- 1 x Half-threaded Socket Screw M2x10mm.
- 1 x M2 Self-Locking nut.
- 3 x Washer Ø 3x6x0.3mm.
- 3 x Washer Ø 3x4.5x0.2mm.

Spindle Shaft

XL20H150



- 3 x Spindle Shaft Ø 3x15.7mm.
- 6 x Washer Ø 2x4x0.2mm.
- 3 x Head Cap Screw M2x5mm.
- 3 x Button Head Screw M2x5mm.

Swashplate SET

XL20H160



- 1 x Swashplate upper 3-blades.
- 1 x Swashplate lower.
- 1 x Bearing Ø 15 Ø 21x4mm.
- 1 x GE4C Bearing Ø 4 Ø 12x3mm.
- 6 x Uniball 3.28 M1.6x2mm.
- 1 x Long ball head 3.28 M1.6x2mm.

Balancing Weight

XL20H170



- 1 x Brass weight block Ø 2x6x7.1mm.
- 1 x Half-threaded Socket Screw M2x10mm.

3-Blades Rotor Head SET

XL20H300

